

噴墨印表機專用墨水匣型號對照表

系列	印表機型號	黑色墨水匣	彩色墨水匣
A4 四色系列	EPSON STYLUS 800 / 800+ / 800C / 800C+	S020039 雙包裝	-----
	EPSON STYLUS 820 / II / IIs	S020047	S020049
	EPSON STYLUS COLOR 400 / 440 / 460 / 600 / 640 / 660 / 670	T050150	T052050
	EPSON STYLUS COLOR 480(SXU) / 580 / C20 / C40(系列)	T013052 雙包裝	T014051
	EPSON STYLUS C41 / C43UX / C45(系列)	T038150	T039050
	EPSON STYLUS C60 / C61	T028051	T029051
	EPSON STYLUS C63 / C65 / C83 C63mini / C65mini	T046150	T047250 (藍) T047350 (紅) T047450 (黃)
	EPSON STYLUS C67 / C67mini	T062150 (高印量) T063150 (標準印量)	T0632 (藍) T0633 (紅) T0634 (黃)
	EPSON STYLUS C80	T032150	T032250 (藍) T032350 (紅) T032450 (黃)
	EPSON STYLUS C82	T032150	T042250 (藍) T042350 (紅) T042450 (黃)
	EPSON STYLUS PHOTO R250	T056150	T056250 (藍) T056350 (紅) T056450 (黃)
	EPSON STYLUS COLOR 680	T017051	T018051
	EPSON STYLUS COLOR 740 / 800 / 850 / 860	T051150	T052050
	EPSON STYLUS COLOR 880	T019051	T020051
	EPSON STYLUS COLOR 900 / 980	T003052 雙包裝	T005051
	EPSON STYLUS ProXL	S020034	S020036
	EPSON STYLUS ProXL+	S020034	S020066
	EPSON STYLUS PRO 5000	S020118	S020122 (黃) S020143 (紅) S020147 (藍)
A3(含以上) 四色系列	EPSON STYLUS COLOR 1160 / 1520	T051150	T052050
	EPSON STYLUS 1000	S020039 雙包裝	-----
	EPSON STYLUS 1500 / 1500C	S020062	S020049 (第一次安裝須增購"彩色組件")
	EPSON STYLUS COLOR 3000	S020118	S020122 (黃) S020126 (紅) S020130 (藍)
A4 相片系列	EPSON STYLUS PHOTO 700 / 710 / 720 / 750 / IP100	T050150	T053050
	EPSON STYLUS PHOTO 790 / 870(SE) / 875DC / 890 / 895 / 915(系列)	T007051	T008051
	EPSON STYLUS PHOTO 810 / 830(系列) / 925 / 935	T026051	T027051
	EPSON STYLUS PHOTO 950	T033150	T033250 (藍) T033350 (紅) T033450 (黃) T033550 (淡藍) T033650 (淡紅)
	EPSON STYLUS PHOTO 900	T007051	T009051

系列	印表機型號	黑色墨水匣	彩色墨水匣
A4 相片系列	EPSON STYLUS PHOTO R210 / R230 R310 / R350	T049150	T049250 (藍) T049350 (紅) T049450 (黃) T049550 (淡藍) T049650 (淡紅)
	EPSON PictureMate (新一代六色 魔珠)	T5570 (PictureMate印相組合)"相片墨水匣 +100張優質照片紙" T5570G (相片墨水匣)	
A3(含以上)	EPSON STYLUS PHOTO 1200	T050150	T001051
	EPSON STYLUS PHOTO 1270 / 1290	T007051	T009051
A3 七色系列	EPSON STYLUS PHOTO EX / EX2 / EX3	T050150	T053050
	EPSON STYLUS Photo 2100	T034150(黑) T034750(淡黑) T034850(消光黑)	T034250(藍) T034350(紅) T034450(黃) T034550(淡藍) T034650(淡紅)
A4 八色系列	EPSON STYLUS PHOTO R800 / R1800	T054050(超光澤黑) T054850 (消光黑) T054150 (亮黑)	T054250 (青) T054350 (紅) T054450 (黃) T054950 (藍) T054750 (酒紅色)
	EPSON STYLUS PHOTO R2400	T0591(亮黑) T0597(淡黑) T0598(消光黑) T0599(超淡黑)	T0592(藍) T0593(紅) T0594(黃) T0595(淡藍) T0596(淡紅)
A3 八色系列	EPSON STYLUS PHOTO R2400	T0591(亮黑) T0597(淡黑) T0598(消光黑) T0599(超淡黑)	T0592(藍) T0593(紅) T0594(黃) T0595(淡藍) T0596(淡紅)
相片 複合機	EPSON STYLUS CX1500	T038150	T039050
	EPSON STYLUS CX3100	T028051	T029051
	EPSON STYLUS CX3500	T046150	T047250 (藍) T047350 (紅) T047450 (黃)
	EPSON STYLUS CX5100 / CX5300	T032150	T042250 (藍) T042350 (紅) T042450 (黃)
	EPSON STYLUS CX3700 / CX4100 / CX4700	T062150 (高印量) T063150 (標準印量)	T0632 (藍) T0633 (紅) T0634 (黃)
	EPSON STYLUS PHOTO RX430	T056150	T056250 (藍) T056350 (紅) T056450 (黃)
	EPSON STYLUS PHOTO RX510 / RX630	T049150	T049250 (藍) T049350 (紅) T049450 (黃) T049550 (淡藍) T049650 (淡紅)
	EPSON STYLUS COLOR SCAN 2000 / 2500	T051150	T052050